

Barbie






IN THE

Nutcracker™



INSTRUCTIONS

CONTENTS



Colors and decorations may vary from those shown.

Please remove everything from the package and compare to the contents shown here.
If any items are missing, please call 1-800-524-TOYS.




50792-0920

Keep these instructions for future reference as they contain important information.

Your doll can “dance” on her dance stand.


- 1.** Attach the top clip of the doll stand to the base. Be sure the side rib is down.



- 2.** Slide the doll *backward* into her doll stand, with the clip going *over* her clothes.




- 3.** Place the doll's toes into the base slots, if you are posing your doll with her ballerina feet pointed. Place the doll stand into the slots on the dance stand.




The top of the doll stand has two positions:

- A.** Use when your doll is on the dance stand alone, and her toes are pointed.
- B.** Use when your doll is posed in any other position or when two dolls are on the dance stand together.



Your doll has specially designed arms and legs allowing her to be posed in actual ballet positions.



4.

Twirl your doll by moving the dance stand back and forth on a smooth flat surface.




Your doll can also dance with her Prince.

(For dance stand doll placement, see the back of the instructions.)


Ken® doll Prince Eric sold separately, subject to availability.




To remove the doll stand from the dance stand, gently lean back the doll and doll stand until the doll stand comes out of the slots.




Clip on the tiara onto your doll's hair (A). Wrap the ribbon around the doll's hair (B). Bring ribbon up and over the tiara's post, looping the ends around the post (C), as shown.



Peel hair jewels from the sheet and apply to your doll's hair.




One doll or two dolls can be arranged on Barbie® doll's dance stand.



One doll, on a doll stand, placed *only* in the *center* area (A).

Two dolls, each on a doll stand, placed in the *outside* areas (B).

For best results, Barbie® and Ken® dolls dance together, and Kelly® and her Little Friends dance together. Do not mix dolls of different heights.



TWO YEAR LIMITED WARRANTY

Mattel, Inc. warrants to the original consumer purchaser that this product will be free of defects in material or workmanship for two years (unless specified in alternate warranties) from the date of purchase. If defective, return the product along with proof of the date of purchase, postage prepaid, to Consumer Relations, 636 Girard Avenue, East Aurora, New York 14052 for replacement or refund at our option. This warranty does not cover damage resulting from unauthorized modification, accident, misuse or abuse. In no event shall we be responsible for incidental, consequential, or contingent damages (except in those states that do not allow this exclusion or limitation). **VALID ONLY IN U.S.A.** This warranty gives you specific legal rights and you may also have other rights which vary from state to state. Some states do not allow the exclusion of incidental or consequential damages, so the above exclusions or limitations may not apply to you.

Send only the product to the address above. Send all correspondence to Consumer Relations, Mattel, Inc., 333 Continental Blvd., El Segundo, California 90245-5012 U.S.A. Or you may phone us toll-free at 1-800-524-TOYS, Monday – Friday, 8:00 a.m. – 6:00 p.m. Eastern Time. Outside U.S.A., see telephone directory for Mattel listing.

CONSUMER INFORMATION

MATTY MATTEL™ toys



YOU CAN TELL IT'S MATTEL!™ CALL us toll-free or write with any comments or questions about our products or service. Monday-Friday 8:00 a.m.-6:00 p.m. Eastern Time. Outside U.S.A., see telephone directory for Mattel listing.

Consumer Relations, Mattel, Inc.
333 Continental Blvd.
El Segundo, CA 90245 USA

1(800) 524-TOYS

WE ARE DEDICATED TO QUALITY PRODUCTS.

 **WARNING:**

CHOKING HAZARD – Small parts.
Not for children under 3 years.