


Barbie®



TOTALLY HAIR™ styling head

INSTRUCTIONS CONTENTS



Each sold separately and subject to availability.

To remove from box, pull the ends of strips to release the hair, and remove any remaining thread from doll's hair.

CONSUMER INFORMATION

Need Assistance? Visit service.mattel.com or call 1-800-524-8697 (US and Canada only), M-F 9AM - 7PM & SAT 11AM - 5PM, Eastern.

SERVICE.MATTEL.COM

Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A.
Consumer Relations 1 (800) 524-8697.

Mattel Canada Inc., Mississauga, Ontario L5R 3W2. You may call us free at/ Composez sans frais le 1-800-524-8697.

Mattel U.K. Ltd., Vanwall Business Park, Maidenhead SL6 4UB.

Mattel Australia Pty., Ltd., Richmond, Victoria 3121. Consumer Advisory Service 1300 135 312 (valid only in Australia).

Mattel East Asia Ltd, Room 1106, South Tower, World Finance Centre, Harbour City, Tsimshatsui, HK, China.

Diimport & Diedarkan Oleh: Mattel SEA Ptd Ltd.(993532-P) Lot 13.5, Menara Lien Hoe, Persiaran Tropicana Golf Country Resort, 47410

WARNING:
CHOKING HAZARD - Small parts.
Not for children under 3 years.

Please remove everything from the package and compare to the contents shown here. If any items are missing, please call 1-800-524-8697.

Keep these instructions for future reference as they contain important information.


©2007 Mattel, Inc., 333 Continental Blvd., El Segundo, CA 90245 U.S.A. All Rights Reserved.

Bling it Out! 20+ Glam Hair Accessories!

1

Lay the "gems" with the fabric fastener down on a hard surface, such as a table or countertop.

2



To load the "gems", hold the jewel applicator with the open tip pointed downward. Press down on the "gem". Load up to 10 "gems". Stop pressing when no more "gems" can be inserted.

3

To put a "gem" on doll's hair, place the open tip on the desired area, and press the button to release the "gem" onto the hair. Try not to do this quickly, as you may get more than 1 "gem".

